

R134a 饱和温度与压力参照表

温度 t/℃	50	49	48	47	46	45	44	43	42
压力 P/bar	13.176	12.851	12.529	12.213	11.903	11.599	11.301	11.009	10.722
温度 t/℃	41	40	39	38	37	36	35	34	33
压力 P/bar	10.441	10.166	9.896	9.631	9.372	9.118	8.870	8.623	8.388
温度 t/℃	32	31	30	29	28	27	26	25	24
压力 P/bar	8.153	7.925	7.702	7.483	7.269	7.059	6.854	6.653	6.457
温度 t/℃	23	22	21	20	19	18	17	16	15
压力 P/bar	6.266	6.079	5.896	5.717	5.542	5.371	5.205	5.042	4.884
温度 t/℃	14	13	12	11	10	9	8	7	6
压力 P/bar	4.728	4.577	4.431	4.286	4.147	4.009	3.876	3.746	3.620
温度 t/℃	5	4	3	2	1	0	-1	-2	-3
压力 P/bar	3.496	3.376	3.259	3.146	3.035	2.928	2.823	2.722	2.623
温度 t/℃	-4	-5	-6	-7	-8	-9	-10	-11	-12
压力 P/bar	2.527	2.452	2.343	2.255	2.169	2.086	2.006	1.929	1.852
温度 t/℃	-13	-14	-15	-16	-17	-18	-19	-20	-21
压力 P/bar	1.781	1.706	1.646	1.584	1.510	1.446	1.389	1.3338	1.271
温度 t/℃	-22	-23	-24	-25	-26	-27	-28	-29	-30
压力 P/bar	1.216	1.167	1.113	1.064	1.016	0.971	0.927	0.884	0.847